

Basin Cleaning Procedures

WARNING: It is very important that you carefully follow the basin cleaning procedures below to ensure that the spa is sanitized after each use. T4 is not liable for any infections or disease that may result from improper cleaning or failure to adhere to sanitation requirements.

T4 recommends the following disinfectant procedure.

Please check with the State Board code in your area for specific spa disinfectant procedures.

After Each Customer

1. Remove suction cover by turning counter-clockwise. Remove any debris present with water spray.
2. Spray Sanitex disinfectant on impeller.
3. Spray Sanitex disinfectant on both sides of suction cover.
4. Thoroughly clean inside surface of spa tub, foot rest, and arm rest with Sanitex disinfectant wipes.
5. Thoroughly clean rest of the spa basin surface with Sanitex disinfectant wipes.
6. Allow 10 minutes for disinfecting time to complete.



Remove suction cover by turning counter-clockwise.



Spray impeller.



Spray suction cover on both sides



Replace suction cover by turning clockwise. Clean inside basin with disinfectant wipes



Clean the rest of the spa tub, footrest, and armrest with disinfectant wipes.

Every Night

1. Remove suction cover by turning counter-clockwise.
 2. Use a soft brush and water to clean suction cover.
 3. Use a soft brush and water to clean impeller. Put suction cover back in its place by turning clockwise.
 4. Add 1 level scoop of Pedi-Clear disinfectant crystals or other EPA Approved cleaner. (follow manufacturer's instructions)
 5. Circulate for 10 minutes and let it soak overnight.
 6. The next morning, drain water and thoroughly clean inside surface of spa basin with Sanitex disinfectant wipes.
 7. Thoroughly clean rest of the spa tub surface with Sanitex disinfectant wipes.
- The unit is now ready for the first customer of the day.



Recommended EPA Approved Hospital Grade Items:

Sanitex Spray
EPA Approved & Hospital Grade



Sanitex Wipes
EPA Approved & Hospital Grade



**Pedi-Clear
Disinfectant
Crystals**
EPA Approved

